





INSTALLATION INSTRUCTIONS



Astra 5dr

VAU-ASTR-5-A


Parts List




INSTALLATION INSTRUCTIONS - VAU-ASTR-5-A

1


ATTACH BEHIND RUBBER SEAL



2



3



INSTALLATION INSTRUCTIONS - VAU-ASTR-5-A

